

Foaming Make-up Remover <Pump> DMS-14S-5

Easy-to-use self foaming-type make-up remover.

AMILITE GCS-12K is employed for its foamability and fresh skin afterfeel.

(wt%)		
A	HYDROGENATED POLYISOBUTENE*1	1.10
	PEG-20 GLYCERYL TRIISOSTEARATE*2	2.70
	FRAGRANCE	q.s.
B	WATER	balance
	ISOPENTYLDIOL*3	10.00
	GLYCERIN	10.00
	AMILITE GCS-12K (30%)	10.00
	LAURAMIDOPROPYL HYDROXYSULTAINE (30%)*4	14.00
	LAURYL GLUCOSIDE (50%)*5	2.00
	AMISAFE AL-01	0.02
C	DISODIUM EDTA	0.10
	PRESERVATIVES	q.s.
		100.00

- 1 Mix part A until uniform at room temperature.
- 2 Dissolve part B with stirring at 80°C.
- 3 Add part C to B and dissolve at 80°C.
- 4 Cool to 50°C with stirring, add part A to B, stir until uniform.
- 5 Cool to room temperature with stirring.

- | | | |
|-----|--------------------|-----------------------|
| * 1 | PERLEAM EX | NOF |
| * 2 | EMALEX GWIS-320EX | NIHON EMULSION |
| * 3 | ISOPRENE GLYCOL-S | KURARAY |
| * 4 | SOFTAZOLINE LSB | KAWAKEN FINE CHEMICAL |
| * 5 | PLANTACARE 1200 UP | BASF / COGNIS |

pH 7.3
 Viscosity NA
 Stability -5, 25°C, 45oC 1 month

Note; The information is provided based upon our technical data and present knowledge. However, we make no warranties, expressed or implied, and assume no liabilities in connection with any use of the information with respect to specific property, safety and suitability for a specific application. It is also not guaranteed that use of the information does not fall within the scope of any intellectual property rights.