

PRESSED POWDER FOUNDATION PFD-NTPL

AMIHOPE LL imparts creamy feeling in during spreading and moisturized feeling is continued.

TS Data Sheet No. 0501-0780E, -0800E

	PFD-NTPL (wt%)	without AMIHOPE (wt%)	
A TALC *1	20,45	22,45	Extender
SERICITE *2	32,00	32,00	Extender
MICA *3	20,00	20,00	Extender
TITANIUM DIOXIDE *4	8,00	8,00	Pigment
TITANIUM DIOXIDE, ALUMINUM STEARATE *5	3,00	3,00	UV filter
ZINC OXIDE, METHICONE *6	2,00	2,00	UV filter
IRON OXIDE, DIMETHICONE(Red) *7	0,40	0,40	Pigment
IRON OXIDE, DIMETHICONE (Yellow) *8	1,00	1,00	Pigment
IRON OXIDE, DIMETHICONE(Black) *9	0,15	0,15	Pigment
AMIHOPE LL	2,00	-	Sensory improver
B DIMETHICONE *10	4,98	4,98	Emollient, binder
POLYGLYCERYL-2 TETRAISOSTEARATE *11	3,00	3,00	Emollient, binder
DIPENTAERYTHRITYL HEXAHYDROXYSTEARATE/STEARATE/ROSINATE *12	1,00	1,00	Emollient, binder
MINERAL OIL *13	2,00	2,00	Emollient, binder
METHYLPARABEN	0,01	0,01	Preservative
TOCOPHEROL	0,01	0,01	Antioxidant
	100,0	100,0	

- 1 Dissolve part B with heating.
- 2 Weigh all ingredients of part A and pulverize them.
- 3 Mill part A and Part B and pulverize them again .
- 4 Pass the powder to a sieve and then press it.

* 1 JA-68R	YAMAGUCHI MICA
* 2 Sericite GMS-4C	KINSEI MATEC
* 3 Mica Y-2300X	YAMAGUCHI MICA
* 4 CR-50	ISHIHARA SANGYO
* 5 MT-100Z	TAYCA
* 6 MZ-303S	TAYCA
* 7 SA-RED R-516PS (100%)	MIYOSHI
* 8 SA-YELLOW LL-100P (100%)	MIYOSHI
* 9 SA-BLACK BL-100PS (100%)	MIYOSHI
* 10 KF-96A-20cs	SHIN-ETSU
* 11 COSMOL 44V	NISSHIN OILIO
* 12 COSMOL 168ARV	NISSHIN OILIO
* 13 HICALL K-230	KANEDA

Note; The information is provided based upon our technical data and present knowledge. However, we make no warranties, expressed or implied, and assume no liabilities in connection with any use of the information with respect to specific property, safety and suitability for a specific application. It is also not guaranteed that use of the information does not fall within the scope of any intellectual property rights.